



YIC



EVK-YIC51009EBGGB **Evaluation Kit for YIC51009EB Series**


Datasheet

1. Contents of EVK-YIC51009EBGGB




	Item	Description
1.	YIC-GPS-EVK-1009EB	Main Board
2.	YIC-GPS-EVK-1009EB	Adaptor Board
3.	USB Cable	USB Type B to USB Type A
4.	ATGGB4336-SMA-3	Dual Band GNSS L1 Antenna
5.	YIC51009EBGGB	Ultra Low Power & Multi-Constellation GNSS Module

2. Install the PL2303 USB driver to PC

 PL2303_Prolific_DriverInstaller_v1210.exe

2.1 Install the PL2303 USB driver, open the computer control panel, check the corresponding serial port.




3. Connection diagram

3.1 Carefully slide the DUT GPS module into main board, pin 1 of the module corresponds to the arrow on main board



3.2 Test connection




4. For YIC51009EB series (MediaTeK chip based)

4.1 Install test software: GNSS Viewer


4.2 Software setting

- ① Select the corresponding serial port
- ② Select the corresponding baud rate (9600 or 115200,.....)
- ③ Click Connect to start the test



5. LED and Push Button description

5.1 Adaptor Board



- ① Red LED: POWER, always on when power on
- ② Blue LED: RXD, often light while DUT GPS module receiving data
- ③ Green LED: TXD, flash once per second when DUT GPS module start sending data
- ④ Push Button: POWER, push to power on and off the EVK

5.2 Main Board

PPS LED: Flash once per second after satellite position fixed